

DON'T GET SHOCKED

get


BREAK-A-BEAM GROUND GUARD!

**INTERMITTENT CONTROL ISSUES?
HAS YOUR GROUND LET YOU DOWN?
GET UPTIME WITH GROUND GUARD**

- GROUND GUARD continuously "verifies" ground status.
- GROUND GUARD "signals" your controls when machine ground is interrupted.
- GROUND GUARD "protects" your operators from electrical hazards caused by a faulty ground.
- GROUND GUARD "saves" your circuit board and controls equipment from damage caused by an inadequate ground.

Operating voltage: 120/vac.
Relay output: 1 NO/NC contact.
Connections: Wago style (spring type non-screw connector) accepts size 14 thru 20 GA wire.
Fused and solid state protection against over voltage.
Model #G-1000.
Size: 3 3/8" long x 2 1/2" wide.

WIRING DIAGRAM



BREAK-A-BEAM GROUND GUARD

For further technical information contact:
BREAK-A-BEAM, INC.

25257 Mound Road, Warren, Michigan 48091 USA
810-758-7790 Fax 810-758-6436
www.break.a.beam.com

